




## NOTICE

The Service and Repair manual for models ULTRA-1 and ULTRA-2, is currently in progress.  
For your convenience, we have provided Electrical Schematic Diagrams on the following pages.

Thank you for your patience.


### **BUNN-O-MATIC CORPORATION**

POST OFFICE BOX 3227  
SPRINGFIELD, ILLINOIS 62708-3227  
PHONE: (217) 529-6601 FAX: (217) 529-6644





# SCHEMATIC WIRING DIAGRAM ULTRA-2 AF



120 VOLTS AC  
or  
230 VOLTS AC  
2 WIRE  
SINGLE PHASE  
50/60 HZ

230V COMPRESSOR ASSY

